





NOTES:

1. ALL RESISTORS ARE 1/2 WATT 5% UNLESS OTHERWISE NOTED. RESISTOR VALUES ARE IN OHMS (K=1000).
2. ALL CAPACITORS LESS THAN 1 ARE IN μ F, GREATER THAN 1 ARE IN pF.
3. FUNCTION SWITCH SHOWN IN 200 POSITION.
4. CALIBRATE SWITCH SHOWN IN CAL POSITION.
5. SENSITIVITY SWITCH SHOWN PUSHED IN.
6.  THIS SYMBOL INDICATES CIRCUIT BOARD COMMON.
7.  THIS SYMBOL INDICATES CHASSIS GROUND.
8.  THIS SYMBOL INDICATES AN EXTERNAL CONNECTION TO THE CIRCUIT BOARD.
9.  THIS SYMBOL INDICATES A FERRITE BEAD.

SCHEMATIC OF THE HEATHKIT[®]

RF POWER METER MODEL HM-102

PRINTED CIRCUIT BOARD

